



Disinfectant based on lactic acid

Product Description

Keno™san Lactic is a disinfectant for knives and surfaces in the food industry.

Properties

Composition: according to regulation (EU) 528/2012: 24% (w/w) lactic acid (CAS no.: 79-33-4).
Use in PT4 (Biocide for the food industry). Only for professional use. In water soluble solution.

Direction of use

Food industry: Clean the surfaces before application. Use a 10% solution during 2 minutes or use a 1,5% solution during 15 minutes for the disinfection of the surfaces. Way to use: spraying under low pressure.

Commercial kitchens and canteens: Clean the surfaces before application. Use a 10% solution during 2 minutes or use a 1,5% solution during 15 minutes for the disinfection of the surfaces. Way to use: spraying under low pressure.

Disinfection of knives used in intermediate application in the food industry: Pre-rinse the knives. Dip the knives in a solution of 8% for 2 minutes or in a solution of 15% for 30 seconds at a temperature of minimum 7°C. Change the disinfection bath on a regular basis.

Use as much Keno™san Lactic solution to keep the treated surfaces wet during the entire contact time. It is not necessary to permanently dip or spray during the whole contact time. Frequency of application: daily.

Specifications

Physical state	Liquid
Colour	Yellow
pH	ca 2 (100%)
Flash point	51 °C
Density	ca 1.07 kg/l
Solubility in water	100 %

Storage and Disposal

Keep in fireproof place. Keep only in the original container in a cool, well-ventilated place. Keep container closed when not in use. Dispose in a safe manner in accordance with local/national regulations.

Safety instructions for the user

Avoid contact between alkaline and acid products. Always test the product first on a small surface. Consult your Cid Lines sales' person for a suitable cleaning- and disinfecting program that is adjusted according to the contamination and the specific conditions of the company.

Before use, please check the MSDS.

Use biocides safely. Before use, read the label and the information concerning the product.

Not all CID LINES products are available in all countries. For information about availability of a specific product, please contact your CID LINES dealer.

CID LINES

Waterpoortstraat 2, 8900 Ieper (Belgium)
T +32 (0)57 21 78 77 • F +32 (0)57 21 78 79
info@cidlines.com • www.cidlines.com

